



You will need:

1. X01™ or XX1™
Eagle™ derailleur*
2. Ratio Cable Port Plug
3. Ratio Cable Stop Screw
4. Ratio Rear Exit Cable
Stop
5. Two 3 mm hex keys
(Tip: you may have a second hex key on your multitool)

*Note: GX™ derailleur used for illustrative purposes only. The cable pulley on these derailleurs is riveted in place.

STEP 1: PULLEY REMOVAL

 **Ratio**



1. Insert the two hex keys into the axle of the cable pulley.
2. Turn one hex key anticlockwise to remove the cable pulley bolt.
3. Lift the pulley off the derailleur.

STEP 2: CABLE STOP FITTING

Ratio



1. Slot the Ratio Cable Stop into the space left by the cable pulley.
2. Insert the Cable Stop Bolt and use the 3 mm hex key to tighten.
3. Tighten the bolt to 3 Nm.
4. Finally, press the Cable Port Plug into place





Your Eagle™ derailleur is now compatible with all cable routing variations.

