

### UPGRADE KIT CONTENTS





- 1. Upper jockey wheel
- 2. Lower jockey wheel
- 3. 1x12 Road ratchet
- 1. Shifter disassembly screw
- 5. Emergency mint cake

Contents of individual part kits will be a subset of those above



## 1. SHIFTER RATCHET REPLACEMENT



Fit the 1x12 Road ratchet to your shifter. Scan the QR code for your shifter type or visit **ratiotechnology.com** to view our video guide. Make sure that you follow the correct guide.

#### SRAM 11 speed shifters for **hydraulic brakes**



#### SRAM 11 speed shifters for cable brakes



# 2. JOCKEY WHEEL REPLACEMENT





The 1x12 Road kit is compatible with SRAM Exact Actuation™ 1x-specific derailleurs including Force 1™, Rival 1™ and Apex 1™. If you are using a **short cage** derailleur, ensure your cassette is not larger than the **32 tooth limit** for these derailleurs

Use a **3 mm** hex key to remove the original 11 speed jockey wheels. The upper and lower screws are **different**; take care to keep them separate.


Fit your Ratio jockey wheels. With the markings facing outwards, the upper jockey (marked "U") should be on the left as shown and the lower jockey (marked "L") should be on the right. The rotation arrows mark the direction that the jockeys will rotate when the bike is pedalled forwards.



ROAD\_01 05/21

## 3. SHIFTER CABLE ROUTING





Cable brakes only: Pull the lever, then feed the brake cable through the hole and out of the shifter. Connect the brake and check that the operation is normal.

#### Both brake types:

- . Shift the mechanism into the **smallest** sprocket
- 2. Roll the shifter hood back from the base
- 3. Feed the end of your new derailleur cable into the hole at the **bottom** of the shifter
- Ensure that the cable passes through the hole in the red cable spool inside the shifter
- 5. Pull the cable out of the top of the shifter until the end of the cable is **seated in the spool**
- 6. Fit an outer ferrule and then slide the inner cable into the outer housing



## 4. DERAILLEUR CABLE ROUTING






- 1. Fit a ferrule to the end of the outer cable
- Engage the cage lock on the derailleur
- Thread the inner cable through the cable stop and the cable fin
- Pull the cable tight and clamp it with the bolt (3 Nm maximum), ensuring that the cable is seated in the groove in the washer
- 5. Cut the cable to length and clamp an end cap in place

#### 5. Chain length and indexing





- Wrap your 12 speed chain around the chainring and the largest sprocket, missing the derailleur
- 2. Depending on the length of your chainstays, the final link will meet the chain to be cut **anywhere in the range shown**
- Count 3, 4 or 5 links from the meeting point as shown and break the chain, ensuring that the chain ends at an inner link
- 4. If in doubt between 3 or 5 links, **choose 5** it is better to leave the chain **too long**
- 5. Thread the chain through the derailleur and join it with a quick link
- Adjust the lower limit screw until the upper jockey wheel is aligned with the centre of the smallest sprocket
- 7. Use the guide provided with the derailleur to set the **B screw** in the largest sprocket, there should be **14 mm** between the
- sprocket and the upper jockey wheel

  8. Use the clamp bolt and then the barrel adjuster to index the gears.

  If the shifts **inboard** are slow, turn the adjuster **anticlockwise**. If the
- shifts **outboard** are slow, turn it **clockwise**9. Release the upper limit screw. In the largest sprocket, trying to shift to an easier gear should put you back into the **same sprocket**. Turn the limit screw **clockwise** until this doesn't happen, then release it around **half a turn**. The big to big shift should be **firm**



# 4

Ratio Technology was founded in 2018 by Cambridge Engineers
Tom Simpson and Felix Barker to develop groundbreaking drivetrain components. Since then, we've set our minds to creating the parts we want to ride on our own bikes. We hope you enjoy them.

All the best,

Tom and Felix

#ratiotechnology

